

SONAI[®]

Toaster - Toasty

SH-1808



730 W

Instruction Manual



www.sonaiworld.com



1	variable browning control	4	Cancel button
2	Reheat button	5	Bread carriage lever
3	Defrost button	6	Crumb Tray

Save These Instructions

While using electrical appliances, in order to reduce the risk of fire, electric shock or injury to persons, basic safety precautions should be followed, including the following:

- Read all instructions carefully, even if you are familiar with the appliance.
- To protect against the risk of electric shock, DO NOT IMMERSE the appliance, cord set or plug in water or other liquids.
- To clean, wipe the exterior with a damp cloth.
- Close supervision is necessary when any appliance is used near children. Never leave an appliance unattended when in use.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Switch off and remove the plug from the power outlet when not in use before assembling or disassembling parts, cleaning or carrying out any maintenance of the appliance. Never pull the cord while unplugging out from power outlet.
- Do not operate the appliance if it is damaged in any manner. Return the complete appliance to your nearest authorized service facility for examination, electrical repair, mechanical repair or adjustments to avoid any hazard.
- The use of attachments or accessories not recommended or sold by Sonai may result in fire, electric shock or personal injury.
- Do not let the cord hang over the edge of a table, counter, or touch hot surfaces.
- Do not operate or place any part of this appliance on or near any hot surfaces (such as gas or electric burner or in a heated oven).
- Do not abuse the cord. Never carry the appliance by the cord or yank it to disconnect it from the outlet; instead, grasp the plug and pull to disconnect.
- When using an extension cord with your appliance, make sure the extension cord is correctly wired, and rated for its use.
- This product is intended for household use only.
- Do not attempt to repair the appliance yourself; instead, take it to your Authorized Service Centre for repair.
- Always leave sufficient space around the appliance for ventilation.
- Do not use the unit if you have wet hands or bare feet.
- Switch off the appliance before changing accessories or approaching parts which move in use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for

their safety.

- Children must be supervised to ensure that they do not play with the appliance.
- Watch your toaster during use.
- Do not touch the top of the toaster or other hot parts during or directly after use
- Do not insert oversized foods, metal foil packages or utensils into the toaster.
- Do not attempt to dislodge food when the toaster is plugged in and never insert cooking utensils into slots.
- Do not place bread or other items on top of the slots as this may damage your toaster.

Before First Use

- Remove all packaging material.
- Remove any stickers from the appliance.
- Make sure that the appliance is placed on a stable, flat, clean, dry and non-slip surface.

Note:

- The lever will not lock into position if the Toaster is not plugged into a power outlet or if the power outlet is not switched on.
- When your Toaster is heated for the first time, it may emit slight smoke or odor. This is normal and should disappear after 1 or 2 uses.
- The condition of the bread will determine how quickly it toasts. Dry or stale bread toasts faster than fresh bread.

How to Use Your Toasty From Sonai

- 1- Plug the Toaster into a standard domestic power outlet and switch the power outlet ON.
- 2- Place bread into the bread slots and press the lever down until it locks into position.
- 3- Adjust the variable browning control to the desired toast color setting.
 - Choose a setting based on the type of bread you are toasting and your personal preference.
 - Start on a medium setting (4-3) and adjust the variable browning control to a lighter setting (1-2) or darker setting (6-5).
- 4- When toasting is completed, the toast will pop-up and the the toaster automatically shuts down and then pull out power plug to cut electricity.

Reheat Function

Toast can be reheated by placing cold toast in the bread slots, lowering the lever and pressing the reheat button. The toast will be reheated over a short, fixed period of time.

Note: When using the reheat function, keep a close eye on the bread to ensure it doesn't burn.

Cancel Function

The toasting cycle can be stopped at any stage by pressing the Cancel button. The toast will pop up and the Toaster will automatically shut down and then pull out power plug to cut electricity .

Defrost Function

The defrost setting is designed to first defrost and then toast your bread, which extends the toasting cycle slightly.

The defrost function is useful for thawing and toasting frozen bread all in one operation.

- Place bread or crumpets into the bread slots.
- Adjust the variable browning control to the desired toast color setting.

Use these recommended settings:

Settings 1-2: For refrigerated bread and thinner frozen items such as frozen pancakes.

Settings 3-4: For toaster pastries, frozen waffles, and (thin) French toast, and refrigerated thin bagels.

Settings 5-6: For thicker frozen items such as bagels, hand-cut bread, and thick French toast.

- Press the lever down to the locked position and press the defrost button.
- When thawing and toasting are complete, the toast will automatically pop-up and the Toaster will automatically shut down & then pull out power plug to cut electricity.

Notes

- Toasting may be interrupted during the cycle by pushing the Cancel button.
- Wait for 10 to 15 minutes before beginning the next toasting cycle.

This permits the electronically controlled thermostat to reset for the next toasting cycle.

- Do not touch the Toaster walls when the Toaster is in use.
- The lever will not lock into position if the Toaster is not plugged into a power outlet or if the power outlet is not switched on.
- When your Toaster is heated for the first time, it may emit slight smoke or odor. This is normal and should disappear after 1 or 2 uses.
- The condition of the bread will determine how quickly it toasts. Dry or stale bread toasts faster than fresh bread.

- Always unplug the power cord when you are not using the toaster.

Care and Cleaning

- Switch off the power outlet and unplug the Toaster; ensuring you let the Toaster cool before cleaning.
- Wipe over the exterior of the Toaster and power cord with a soft damp cloth.
- Do not use abrasives or strong household cleaners.
- The crumb trays will need to be cleaned occasionally.
- Pull out the crumb tray outward for easy removal of bread crumbs. After cleaning, slide it back to lock into position.

Note: Do not try to clean the inside of the Toaster, as this may damage the heating elements.

Electrical Safety



Always check that the power supply corresponds to the voltage on the rating plate.

To avoid the risk of electric shock, do not immerse the cord, plug or motor unit in water or other liquid.

Protecting the environment



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.

السلامة الكهربائية

التأكد من توافق محول الكهرباء مع الجهد الكهربائي للجهاز في لوحة البيان.
تجنب غمر السلك أو القابس في أي سوائل لتجنب خطر الصدمة الكهربائية.



حماية البيئة

تشير هذه العلامة إلى أنه لا يجب التخلص من هذا المنتج مع النفايات المنزلية الأخرى في جميع أنحاء الاتحاد الأوروبي. لمنع ضرر محتمل للبيئة أو الصحة البشرية من التخلص غير المنضبط من النفايات ، أعد تدويرها مسؤولة تعزيز إعادة الاستخدام المستدام للموارد المادية. لإرجاع جهازك المستخدم ، يرجى استخدام أنظمة الإرجاع والتحصيل أو اتصل ببائع التجزئة حيث تم شراء المنتج. يمكنهم أخذ هذا المنتج لإعادة التدوير الآمن في البيئة.



العناية والتنظيف

- أفصل محمصة الخبز (توستر) عن الكهرباء للتأكد من تركها تبرد قبل تنظيفها.
 - نظف الجزء الخارجي من محمصة الخبز (توستر) وسلك الكهرباء بقطعة قماش مبللة.
 - لا تستخدم مواد خشنة أو منظفات منزلية قوية.
 - يجب تنظيف صينية جمع الفتات بانتظام.
 - قم بإزالة صينية جمع الفتات للخارج لإزالة الفتات بسهولة، وبعد تنظيفها ضعها مرة أخرى في مكانها وقم بتثبيتها.
- تحذير: لا تحاول تنظيف محمصة الخبز (توستر) من الداخل لأن ذلك قد يؤدي إلى تلف جهاز التسخين.

استخدم هذه الإعدادات الموصى بها:

تحميص منخفض 1-2: تُستخدم لتحميص الخبز المبرد والأشياء المجمدة الرفيعة مثل فطائر البان كيك المجمدة.

تحميص متوسط 3-4: تُستخدم لتحميص المعجنات المحمصة والوفل المجمد والخبز الفرنسي (الرقيق) والخبز الرقيق المبرد.

تحميص شديد 5-6: تُستخدم لتحميص الأشياء المجمدة الأكثر سمكًا مثل الخبز والخبز المُقطع يدويًا والخبز الفرنسي السميك.

- اخفض رافعة الخبز حتى تثبت في مكانها واضغط على زر الإذابة.
- عند إنتهاء الإذابة والتحميص، سيظهر الخبز وتتوقف المحمصة تلقائيًا، قم بإزالة مقبس الكهرباء بعد ذلك.

ملاحظات

- يُمكنك إيقاف عملية التحميص أثناء التشغيل من خلال الضغط على زر الإيقاف.
- انتظر 10-15 دقيقة قبل بدأ عملية التحميص التالية.
- هذا يعيد تشغيل الترموستات الالكتروني من أجل عملية التحميص التالية.
- لا تلمس الهيكل الخارجي لمحمصة الخبز (التوستر) أثناء الاستخدام.
- لن يتم تثبيت الرفعه في موضعها إذا لم يتم توصيل محمصة الخبز (التوستر) بمقبس الكهرباء أو إذا لم يتم تشغيلها.
- عند تسخين محمصة الخبز (التوستر) للمرة الأولى، قد ينبعث منها دخان أو رائحة مختلفة وهذا أمر طبيعي وستختفي بعد استخدامها مرة أو مرتين.
- تحدد حالة الخبز سرعة تحميصه؛ يُحمص الخبز الجاف أو الناشف أسرع من الخبز الطازج.
- انزع القابس الكهربائي دائمًا في حالة عدم استخدامها.

- الاستخدام أو بعده مباشرةً.
- لا تضع الأطعمة كبيرة الحجم أو الطعام الملفوف بورق الألومنيوم أو الأدوات في محمصة الخبز (التوستر).
- لا تحاول إخراج الطعام عندما تكون محمصة الخبز (التوستر) موصولة بالكهرباء ولا تضع أدوات الطعام أبدًا في الفتحات.
- لا تضع الخبز أو أي شيء آخر فوق الفتحات حيث قد يؤدي ذلك إلى تلفها.

قبل الاستخدام لأول مرة

- قم بإزالة جميع مواد التغليف.
- قم بإزالة أي ملصقات من على الجهاز.
- تأكد من وضع الجهاز على سطح مستو ونظيف وجاف وغير قابل للإنزلاق.

طريقة استخدام محمص الخبز توستي من سوناى

- 1- قم بتوصيل محمصة الخبز (التوستر) بمقبس كهرباء منزلي وقم بتشغيلها.
- 2- ضع الخبز في فتحة الخبز واخفض رافعه الخبز حتى تستقر في مكانها.
- 3- اضبط إعدادات بكرة التحكم المختلفة على درجة التحميص التي تفضلها.
- اختر الإعدادات وفقًا لنوع الخبز الذي تُحمسه ودرجة التحميص التي تفضلها.
- ابدأ بدرجة تحميص متوسطة (3-4) ثم اضبط إعدادات بكرة التحكم على درجات التحميص المنخفضة (1-2) أو المرتفعة (5-6).
- 4- عند الانتهاء من عملية التحميص يخرج الخبز وتتوقف المحمصة تلقائيًا، قم بإزالة مقبس الكهرباء بعد ذلك.

خاصية إعادة التسخين

- يُمكن إعادة تسخين الخبز من خلال وضع الخبز البارد في فتحات الخبز وخفض رافعة الخبز ثم الضغط على زر إعادة التسخين، وسيتم إعادة تسخين الخبز في وقت قصير.
- ملحوظة:** عند استخدام خاصية إعادة التسخين، راقب الخبز جيدًا لضمان عدم حرقه.

خاصية الإيقاف

- يُمكنك إيقاف عملية التحميص في أي وقت أثناء التشغيل من خلال الضغط على زر الإيقاف. سيظهر الخبز وتتوقف المحمصة تلقائيًا، قم بإزالة مقبس الكهرباء بعد ذلك.

خاصية إذابة الخبز المُجمد

- صُممت هذه الخاصية لإذابة الخبز أولاً ثم تحميصه وذلك يزيد من وقت عملية التحميص. توفر لك إذابة الخبز وتحميصه في عملية واحدة.
- ضع الخبز أو الفطائر الصغيرة في فتحات الخبز.
 - اضبط إعدادات بكرة التحكم درجة التحميص التي تفضلها.

إرشادات هامة

- هناك احتياطات سلامة يجب إتباعها أثناء استخدام الأجهزة الكهربائية للتقليل من خطر الحريق والصدمة الكهربائية أو إصابة الأشخاص وتشمل هذه الاحتياطات ما يلي:
- قراءة كل هذه التعليمات بعناية حتى ولو كنت على دراية باستخدام الجهاز.
- لا تغمر الجهاز أو مجموعة الأسلاك أو القابس في الماء أو السوائل الأخرى حتى لا تتعرض لصدمة كهربائية.
- استخدم قطعة قماش مبللة لتنظيف ومسح الجزء الخارجى من الجهاز.
- راقب الأطفال عن كثب عند استخدام الجهاز بالقرب منهم. لا تترك الجهاز دون مراقبة أثناء استخدامه.
- فى حالة تلف سلك الطاقة، يرجى الإستعانة بمصنوع الجهاز أو وكيل الخدمة المعتمدة أو أى فنى على نفس درجة التأهيل لإستبدال السلك التالف وذلك لتجنب أى مخاطر ممكنة.
- قم بفصل الجهاز وانزع القابس من مأخذ التيار الكهربائى أثناء عدم الإستخدام أو قبل تركيب أو فك أجزائه أو تنظيف أو إجراء صيانة للجهاز. لا تشد السلك لنزع القابس من مأخذ التيار الكهربائى.
- لا تشغل الجهاز بسلك أو قابس تالف، يجب الإستعانة بمركز الخدمة المعتمدة لمعاينة الجهاز أو إصلاحه كهربائياً أو ميكانيكياً لتجنب أى خطر.
- قد تترتب مخاطر الحريق أو الصدمة الكهربائية أو إصابة الأفراد عند استخدام الملحقات الثانوية التى لم توصى بها سوناي أو تقوم ببيعها.
- لا تدع السلك يتدلى فوق حافة المنضدة أو يلامس أسطحاً ساخنة.
- لا تضع الجهاز أو أى جزء من أجزائه على أسطح ساخنة (مثل فرن غاز أو فرن كهربائى ساخن أو فى فرن تم إحمائه) أو بالقرب منها.
- لا تسيء استخدام السلك ولا تحمل الجهاز أبداً عن طريق السلك أو شده لفصله من مأخذ التيار اقبض على القابس دائماً واسحبه لفصله.
- فى حالة استخدام سلك تمديد، يرجى التأكد من توصيله بشكل سليم وأنه صالح للإستخدام مع هذا الجهاز.
- هذا الجهاز معد للإستخدام المنزلى فقط.
- لا تحاول إصلاح الجهاز بنفسك، ولكن استعن بأقرب مركز خدمة تابع أو معتمد لإصلاح الجهاز.
- احرص دائماً على ترك مساحة كافية حول الجهاز للتهوية.
- لا تستخدم الوحدة إذا كانت يداك مبتلتين أو قدمك عاريتين.
- افصل التيار الكهربائى عن الجهاز قبل تغيير الأدوات الملحقة أو الإقتراب من الأجزاء التى تتحرك أثناء الإستخدام.
- هذا الجهاز غير معد لإستخدامه من جانب أشخاص (بمن فى ذلك الأطفال) لديهم قدرات جسدية وحسية وعقلية منخفضة، أو تنقصهم الخبرة والمعرفة، مالم يكونوا قد حصلوا على إشراف أو تعليمات بشأن استخدام الجهاز من جانب شخص مسئول عن سلامتهم.
- يجب مراقبة الأطفال والإشراف عليهم للتأكد من عدم عبثهم بالجهاز.
- عند استخدام محمصة الخبز (التوستر) يجب التواجد أمامها.
- لا تلمس الجزء العلوي من محمصة الخبز (التوستر) أو الأجزاء الساخنة الأخرى أثناء



زر الإيقاف	4	بكرة التحكم بدرجات التحميص	1
رافعة الخبز	5	زر إعادة التسخين	2
صينية جمع الفتات	6	زر إذابة الخبز المُجمد	3

SONAI®

محمص الخبز - توستي

SH-1808



730 W

تعليمات التشغيل



www.sonaiworld.com