

SONAI[®]

Food Master 1000

SH-3800



1.75 L

Instruction Manual



www.sonaiworld.com



1	Security lid	15	Lid of juice extractor
2	Button for opening security lid	16	Juicer
3	On / Off button	17	Reamer
4	Pulse button	18	Lid of blender
5	Motor housing	19	Small lid of blender
6	Motor shaft	20	Main lid
7	Juice extractor	21	Pusher of main lid
8	Blade holder	22	Chopping blade
9	Spatula	23	Dough blade
10	Blades (shredding thin & thick, slicing thin & thick, grating and French fries)	24	Chopping blade protector
11	Plastic whisking attachment	25	Blade stand
12	Blender	26	Blade stand cover
13	Bowl	27	Grinder attachment
14	Pusher of juice extractor lid		

Save These Instructions

While using electrical appliances, in order to reduce the risk of fire, electric shock or injury to persons, basic safety precautions should be followed, including the following:

- Read all instructions carefully, even if you are familiar with the appliance.
- The blades are very sharp! Handle with care.
- To protect against the risk of electric shock, DO NOT IMMERSE the appliance, cord set or plug in water or other liquids.
- To clean, wipe the exterior with a damp cloth.
- Close supervision is necessary when any appliance is used near children. Never leave an appliance unattended when in use.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Switch off and remove the plug from the power outlet when not in use before assembling or disassembling parts, cleaning or carrying out any maintenance of the appliance. Never pull the cord while unplugging out from power outlet.
- Do not operate the appliance if it is damaged in any manner. Return the complete appliance to your nearest authorized service facility for examination, electrical repair, mechanical repair or adjustments to avoid any hazard.
- The use of attachments or accessories not recommended or sold by Sonai may result in fire, electric shock or personal injury.
- Do not let the cord hang over the edge of a table, counter, or touch hot surfaces.
- Avoid touching hot surfaces, use handles and knobs.
- Do not operate or place any part of this appliance on or near any hot surfaces (such as gas or electric burner or in a heated oven).
- Do not abuse the cord. Never carry the appliance by the cord or yank it to disconnect it from the outlet; instead, grasp the plug and pull to disconnect.
- When using an extension cord with your appliance, make sure the extension cord is correctly wired, and rated for its use.
- This product is intended for household use only.
- Do not attempt to repair the appliance yourself; instead, take it to your Authorized Service Centre for repair.
- Always leave sufficient space around the appliance for ventilation.
- Do not use the unit if you have wet hands or bare feet.
- Switch off the appliance before changing accessories or approaching parts which move in use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or

instruction concerning use of the appliance by a person responsible for their safety.

- Children must be supervised to ensure that they do not play with the appliance.
- Do not let cord hang over sharp edges, or touch hot surfaces or hot oils
- Blades are sharp, handle carefully, when handling the chopper blade, always hold it by the upper plastic part
- To reduce the risk of injury, never place cutting blades or discs on the base without first putting bowl properly in place.
- Be certain cover is securely locked in place before operating appliance.
- Never feed food by hand, always use food pusher.
- Do not attempt to defeat the cover interlock mechanism.
- Always operate blender with cover in place.
- When blending hot liquids, remove the small lid of the blender.
- Do not use the appliance if juicer filter is damaged or broken.
- Make sure that the unit is unplugged from power source and operating button is on "OFF" before inserting or removing attachments.

Before First Use

- Remove all packaging material.
- Remove any stickers from the appliance.
- Make sure that the appliance is placed on a stable, flat, clean, dry and non-slip surface.

Important information:

Please read all the following instruction carefully, for your protection, food processor has a double safety device so that it cannot run unless the main lid (20) is locked in place and the security cover (1) is closed or the blender (12) is also locked in place.

Please note:

1- To open security cover (1) or remove blender (12), you must first remove the main lid (20).

2- To operate the food processor, security cover (1) must be properly closed, push the button (2) for opening the security cover (1).

3- To operate blender (12) main lid (20) must be locked in place.

4- When operating blender (12), make sure that all attachments are first removed from food processor bowl (13).

5- Do not attempt to use both blender and food processor at the same time.

6- Do not attempt to defeat the security cover (1) interlock mechanism or the main lid (20) interlock.

How To Use Your Food Master 1000 From Sonai

Control panel

- After properly closing the security cover, correctly locating the bowl (13) and locking the main lid (20), turn the operation button (3) to activate the unit from its off position.
- For intermittent use, press onto "PULSE" button (4).

1- Food Processing:

- 1- Place the bowl (13) on the motor block (5), there is no need to turn it, it will lock in place by itself.
- 2- Place the chopping blade (22) on the shaft (6) inside the bowl.
- 3- Make sure that the chopping blade is correctly positioned in its place.
- 4- Place the ingredients to be processed in the bowl.

Important: The food processing unit will not operate if the security cover (1) is not closed, this must be done before the bowl is locked in place.

Warning

- Use extreme caution, blades are sharp, handle carefully, always hold the chopping blade by the upper plastic part, after using the chopping blade, always take it out of the bowl (13) before removing the processed food.
- Always store the chopping blade with its protective cap on (24)
- Place the main lid (20) on the bowl and guide the nozzle on the lid into the safety lock opening in the motor block, until you hear it snap in place, turn the appliance on.
- Keep hands and utensils away from the cutting blade while chopping food, to reduce the risk of severe injury to persons or damage to the food chopper, a scraper may be used, but must be used only when the food processor is not running.
- Never feed food by hand, always use food pusher (21).

Processing Examples

The processing times indicated are approximate and also depend on the quality of the food to be processed and the degree of fineness you require

Product	Quantity	Recommended levels	Operation times
Meat	700g	Max	10-20 sec.
Onions	700g	10-15	10-20 sec.
Nuts	600g	20-Max	10-20 sec.
Fish	700g	1-20	10-20 sec.
Cheese	700g	1-20	10-20 sec.
Liquid (soup)	700g	1-20	20 sec.
Carrots	700g	15-20	20 sec.
Bread	4 pieces	15-20	10-20 sec.
Apples	700g	20-Max	10-20 sec.
Parsley	Max. 4 bundles	Max	10 sec.
Mayonnaise	Max. 4 cups / 1lt	20-Max	10 sec.

2- Dough Making:

- 1- Make sure the security lid (1) is closed.
- 2- Place the bowl on the motor block.
- 3- Insert the dough blade (23) on the shaft (6) inside the bowl.
- 4- Place ingredients in the bowl.
- 5- Place the main lid (20) and lock it.

Notes

- Recommended operation speed level is MAX.
- Maximum capacity for processing dough is based on the mixture of 600g. Of flour plus 400g. Of water in order to obtain 1 kg. of dough, when preparing knead dough, do not operate the machine longer than 20 seconds afterwards wait at least two minutes before operating the

machine again.

- For your safety, keep the pusher in its place while operating the appliance.

3- Whisking:

- 1- Make sure the security lid (1) is closed.
- 2- Place the bowl on the motor block.
- 3- Place the plastic whisking attachment (11) into the bowl.
- 4- Place ingredients in the bowl.
- 5- Place the main lid (20) and lock it.

4- Citrus Juicer:

- 1- Make sure the security lid (1) is closed.
- 2- Place the bowl on the motor block.
- 3- Place the citrus juicer filter (16) on the bowl and lock it by turning it.
- 4- Put on the juicer reamer (17).
- 5- Operation speed level for citrus juicer is MIN. do not operate the juicer at higher speed.

Caution: Always operate the juicer only at minimum speed.

5- Slicer / Shredder:

- 1- Place the bowl on the motor block.
- 2- Place the blade of your choice on the blade holder (8).
- 3- Place the blade holder (8) onto the bowl.
- 4- Place the main lid (20) on the bowl and lock in place.
- 5- For your safety, always use the pusher (21) to press down the ingredients never feed food by hand.
- 6- Do not overload the bowl, in one operation, you can process MAX. 1.5 kg. of food.

Processing Examples:

- For Parmesan cheese: recommended speed level is between 10-15
- For thick slicing: recommended speed level is between 10-15 (cabbage, carrots, onions).
- For thin slicing: recommended speed level is between 10-15 (cabbage,

carrots, onions).

- For thin shredding: recommended speed level is between 10-15 (cabbage, carrots, onions).
- For thick shredding: recommended speed level is between 10-15 (lettuce, carrots, apples).
- For French fries: recommended speed level is between 10-15.

6- Grinder Attachment:

- 1- Place the grinder attachment body onto the food processor.
- 2- Put your ingredients into the grinder attachment body and fill it no more than MAX. line.
- 3- Place the grinder attachment lid onto the body and lock it by turning the correct way up, then press the on/off button.
- 4- For grinding: grains, nuts, coffee beans, use the pulse button for 10 to 30 sec.

7- Blender:

- 1- Remove the bowl (13) and main lid (20).
- 2- Open the security cover by pushing the button (2), security cover can be opened only after the main lid (20) is removed.
- 3- Place the blender on its place.

Important:

- Place the bowl without any attachments on, and place the main lid and lock it in place.
- Blender will not operate when lid (20) is not locked in place, the bowl must be empty and without attachments when blender is used.
- Place the lids of the blender (18,19).
- Recommended speed levels for blending are between 5-MAX, for soft vegetables and fruits (e.g.: banana), start with low speed then increase according to your needs, for hard vegetables and fruits (e.g.: carrots) always use the highest speed or MAX.
- Do not load the blender with more than 300gr. Of hard vegetable and fruit in one time, do not operate continuously more than 20 sec. in the blender.
- You can crush 250gr. Of ice in 15-20 sec. in the blender.

- To prevent spilling, do not operate the blender with more than 1000ml. of liquid.
- Always operate the blender with cover in place.
- When blending hot liquids, remove the small lid (19).
- Avoid contact with moving parts at all times, and keep hands, hair, clothing as well as spatulas and other utensils out of the container while blending, a spatula may be used, but must be used only when the unit is not running.
- To remove blender, you must first remove the main lid (20).

8- Juice Extractor:

- 1- Place the bowl on the motor unit, then place the juice extractor filter (7).
- 2- Place the juice extractor lid (15) and lock it.
- 3- The recommended speed level is MAX.
- 4- For your safety, always use the pusher to press down the ingredient
- 5- Always make sure juicer lid is locked securely in place before motor is turned on, do not remove the juice extractor lid (15) while operating.
- 6- During use, turn "OFF" the appliance temporarily to clean the pulp that remains in the filter, with the help of the spatula (9).
- 7- Be sure to turn switch to "OFF" position after each use, make sure the motor stops completely and unplug unit before disassembling.
- 8- Do not put your fingers or other objects into the juicer opening while it is in operation, if food becomes lodged in the opening, use food pusher (21) or another piece of fruit or vegetables to push it down, when this method of removing food lodged in the opening is not possible, turn the motor "OFF" and disassemble juicer to remove the remaining food.

Cleaning and Maintenance

- Make sure that the unit is unplugged from power source and operating button is on "OFF" before inserting or removing attachments.
- Never immerse the unit or cord or plug in water.
- Clean the motor block with a damp cloth only.
- Only the stainless steel blades can be washed in the dishwasher.
- All other parts can be cleaned in warm water using regular dishwashing liquid.

- For cleaning blender: fill with warm water, place cover, run blender at MAX. speed, rinse and repeat if necessary.

Electrical Safety



Always check that the power supply corresponds to the voltage on the rating plate.
To avoid the risk of electric shock, do not immerse the cord, plug or motor unit in water or other liquid.

Protecting The Environment



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.

السلامة الكهربائية

التأكد من توافق محول الكهرباء مع الجهد الكهربائي للجهاز في لوحة البيان.
تجنب غمر السلك أو القابس في أى سائل لتجنب خطر الصدمة الكهربائية.



حماية البيئة

تشير هذه العلامة إلى ضرورة عدم التخلص من المنتج بعد تلافه بالطرق العادية
للتخلص من النفايات المنزلية في دول الإتحاد الأوروبي، لمنع حدوث أى أضرار
محتملة تؤثر سلباً على البيئة أو صحة الإنسان نتيجة لإتباع طرق التخلص من
المخلفات بصورة غير منضبطة أو إعادة تدويرها بشكل يسمح بإعادة إستخدامها
بصورة مستمرة. لكي يتسنى لك إعادة المنتج بعد إستخدامه، يرجى إتباع أنظمة
الإعادة والتجميع أو الإتصال بتاجر التجزئة الذى اشترى منه المنتج حيث يمكنه
تدويره بطريقة آمنة على البيئة.



5- دائما تأكد من غلق غطاء العصارة في مكانه بشكل صحيح قبل تشغيل الجهاز ، لا تقم بإزالة الغطاء (15) أثناء تشغيل الجهاز .

6- أثناء الإستخدام تأكد من غلق الجهاز أثناء تنظيف الفلتر من البواقي بمساعدة المعلقه المسطحه(9)

7- تأكد من غلق الجهاز و فصله عن مصدر الكهرباء و توقف الموتور بشكل كامل قبل فك الجهاز .

8- لا تضع اليدين أو اي اجزاء اخري بداخل العصارة أثناء تشغيل الجهاز، برجاء إستخدام دافع الطعام (21) إذا كان هناك أي طعام موجود بفتحه الغطاء أو اي قطعة خضار أو فاكهه أخري، عندما تكون هذه الطريقة غير ممكنه يجب غلق الجهاز و فك العصارة لإزالة بواقي الطعام.

التنظيف و الصيانه

تحذير: برجاء التأكد أن الجهاز مفصول عن مصدر التيار الكهربائي و ان مفتاح التشغيل علي وضع الإيقاف قبل ادخال أو إزالة اي من الملحقات.

- لا تقم أبدا بغمر الجهاز أو السلك الكهربائي في المياه أو أي سوائل أخري.
- قم بتنظيف وحدة الموتور بقطعة قماش رطبه.
- يمكنك تنظيف الشفرات في غسالة الأطباق.
- باقي الملحقات يمكنك تنظيفها بماء دافئ و صابون.
- لتنظيف الشفثق: إملاه بماء دافئ و صابون، ثم ضع الغطاء، و قم بتشغيل الجهاز علي السرعة القصوي ثم إسطف الشفثق و كرر العملية عند الضرورة.

4- لطحن الحبوب، المكسرات، حبوب البن إستخدم مفتاح النبضات لمدة من 10-30 ثانية.

7- الخلط:

- 1- قم بإزالة شفتق العجن (13) و الغطاء الرئيسي (20).
- 2- إفتح غطاء الأمان بالضغط علي زر فتح غطاء الأمان (2)، غطاء الأمان لا يفتح إلا بعد إزالة الغطاء الرئيسي (20).
- 3- ضع شفتق الخلط في مكانه.

هام:

- ضع شفتق العجن علي وحدة الموتور بدون أي ملحقات، ثم ضع الغطاء الرئيسي وقم بغلقه
- شفتق الخلط لن يعمل إلا إذا كان الغطاء الرئيسي (20) محكم الغلق في مكانه، شفتق العجن يجب أن يكون فارغ و بدون أي ملحقات عند تشغيل شفتق الخلط.
- ضع غطاء الشفتق (18، 19).
- السرعات لموصي بها بين 5 و السرعة القصوي، من أجل خلط الخضروات و الفواكه اللينه (مثل الموز) إبدأ بأدني مستوي للسرعة ثم قم بزيادته طبقا لإحتياجك، من أجل الخضروات و الفواكه الصلبه (مثل الجزر) قم بإستخدام السرعات الأعلى أو القصوي.
- لا تضع في الشفتق أكثر من 300 جرام من الخضروات و الفواكه الصلبه في وقت واحد، و لا تقم بتشغيل الجهاز لأكثر من 20 ثانية في المره الواحده.
- يمكنك سحق 250 جرام ثلج خلال 15 إلي 20 ثانية.
- لتجنب انسكاب السوائل من الشفتق برجاء عدم وضع أكثر من 1 لتر من السوائل.
- دائما إستخدم الشفتق و الغطاء موضوع في مكانه.
- عند خلط سوائل ساخنه قم بإزالة الغطاء الصغير (19).
- تجنب لمس الأجزاء المتحركه و قم بإبعاد اليدين، الشعر، الملابس، الملاعق أو أي ادوات اخري عند تشغيل الجهاز، يمكنك إستخدام الملعقه المسطحه عند وقف الجهاز عن العمل.
- يجب رفع الغطاء الرئيسي (20) أولا ثم إرفع الشفتق.

8- ملحق العصارة:

- 1- ضع شفتق العجن علي وحدة الموتور ثم ضع ملحق فلتر العصر (7).
- 2- ضع غطاء العصارة (15) ثم قم بغلقه.
- 3- السرعه المقترحه هي السرعه القصوي.
- 4- من أجل سلامتك قم بإستخدام دافع الطعام لدفع الطعام بداخل الشفتق.

4- ملحق عصارة الحمضيات

- 1- تأكد أن غطاء الأمان (1) مغلق.
 - 2- قم بوضع شفتق العجن علي وحدة الموتور.
 - 3- ضع ملحق العصارة (16) علي الشفتق و قم بلفها لغلقتها.
 - 4- ضع الملحق المخروطي (17).
 - 5- شغل الجهاز علي أقل سرعه، لا تستخدم ابدا السرعات العاليه.
- تحذير: دائما قم بتشغيل العصارة علي أدني مستوي للسرعه.

5- ملحق الشفرات:

- 1- قم بوضع شفتق العجن علي وحدة الموتور.
- 2- ضع الشفرة التي تريد علي حامل الشفرات (8).
- 3- ضع حامل الشفرات (8) في شفتق العجن.
- 4- ضع الغطاء الرئيسي (20) و قم بإغلاقه.
- 5- من أجل سلامتك دائما إستخدم دافع الطعام (21) لدفع الطعام إلي أسفل لا تضغط الطعام بواسطة يدك.
- 6- لا تضع طعام زائد، يمكنك وضع كمية 1.5 كيلو كحد أقصى من الطعام.

أمثلة:

- الجبنه الرومي: السرعه الموصي بها بين 10-15.
- التقطيع السميك: السرعه الموصي بها بين 10-15 (كرنب، جزر، بصل).
- التقطيع الرفيع: السرعه الموصي بها بين 10-15 (كرنب، جزر، بصل).
- شرائح رفيعه: السرعه الموصي بها بين 10-15 (كرنب، جزر، خيار).
- شرائح سميكه: السرعه الموصي بها بين 10-15 (خس، جزر، تفاح).
- تقطيع بطاطس مقلية: السرعه الموصي بها بين 10-15.

6- المطحنه:

- 1- ضع المطحنه علي وحدة الموتور.
- 2- ضع المكونات التي تريد طحنها بداخل المطحنه، لا تتجاوز مؤشر الحد الأقصى.
- 3- ضع غطاء المطحنه و لفه لإغلاقه، ثم إضغط علي مفتاح التشغيل.

سوائل (شوربة)	700 جرام	1-20	20 ثانية
جزر	700 جرام	15-20	20 ثانية
خبز	4 قطع	15-20	10-20 ثانية
تفاح	700 جرام	20 – السرعة القصوي	10-20 ثانية
بقونس	بحد أقصى 4 حزم	السرعة القصوي	10 ثواني
مايونيز	بحد أقصى 4 أكواب / 1 لتر	20 – السرعة القصوي	20 ثانية

2- وظيفة العجن

- 1- تأكد أن غطاء الأمان (1) مغلق.
- 2- قم بوضع شفثق العجن علي وحدة الموتور.
- 3- قم بوضع ملحق العجن (23) علي عمود الموتور (6) بداخل الشفثق.
- 4- ضع المكونات في الشفثق.
- 5- ضع الغطاء الرئيسي (20) و قم بإغلاقه.

ملاحظات

- سرعة التشغيل الموصي بها هي السرعة القصوي.
- السعه القصوي لعمل العجين تعتمد علي أن يكون مقدار الخليط 600 جرام من الدقيق و 400 جرام من الماء للحصول علي 1 كيلو جرام من العجين، عند تحضير العجين لا تقم بتشغيل الجهاز لأكثر من 20 ثانية متواصلة بعد ذلك انتظر لمدة دقيقتين قبل تشغيل الجهاز مره أخرى.
- من أجل سلامتك دائما إترك دافع الطعام في مكانه أثناء تشغيل الجهاز.

3- الخفق

- 1- تأكد أن غطاء الأمان (1) مغلق.
- 2- قم بوضع شفثق العجن علي وحدة الموتور.
- 3- قم بوضع ملحق الخفق (11) بداخل الشفثق.
- 4- ضع المكونات في الشفثق.
- 5- ضع الغطاء الرئيسي (20) و قم بإغلاقه.

كيفية الإستخدام فود ماستر 1000 من سوناي

لوحة التحكم

- بعد إغلاق غطاء الأمان ووضع شفشق العجن (13) بشكل صحيح و إحكام غلق الغطاء الرئيسي (20) قم بتشغيل مفتاح التشغيل (3) لتشغيل الجهاز.
- من أجل إستخدام متقطع إضغط علي مفتاح النبضات (4).

1-خط الطعام

- 1- قم بوضع شفشق العجن (13) علي وحدة الموتور (5).
 - 2- قم بوضع سكين الفرغ (22) علي عمود الموتور (6) بداخل الشفشق.
 - 3- تأكد أن سكين الفرغ موضوع بشكل صحيح في مكانه.
 - 4- ضع المكونات المطلوب فرمها في الشفشق.
- هام: لا يمكن تشغيل الجهاز إذا لم يكن غطاء الأمان (1) مغلق، يجب غلق الغطاء قبل وضع شفشق العجن في مكانه.

تحذير

- يرجى مراعاة الحذر عند إستخدام سكين الفرغ و الشفرات لانها حاده جدا، يرجى حمل سكين الفرغ من الجزء البلاستيكي العلوي، قم برفع السكين من شفشق العجن (13) بعد الانتهاء من فرم الطعام و قبل سكبه.
- دائما قم بتخزين سكين الفرغ بداخل غطاء الحماية الخاص به (24).
- ضع الغطاء الرئيسي (20) علي شفشق العجن ووجه الغطاء نحو فتحة الأمان الموجوده بداخل وحده الموتور حتي تسمع صوت الغلق ثم يمكنك ان تشغل الجهاز.
- تجنب عدم ملامسة أي أدوات أو ملابس أو شعر للجهاز أثناء تشغيله، من الممكن أن تستخدم الملعقة المسطحة لتقليب الطعام فقط بعد القيام بإغلاق الجهاز.
- لا تقم بدفع الطعام في الجهاز أبدا بواسطة اليد دائما إستخدم دافع الطعام (21).

أمثلة للتشغيل:

أوقات التشغيل المشار إليها تقديرية و تعتمد علي جودة الطعام و درجة الفرغ المطلوبة.

الوقت	السرعة الموصي بها	الكمية	المنتج
10-20 ثانية	السرعة القصوي	700 جرام	لحم
10-15 ثانية	10-15	700 جرام	بصل
10-20 ثانية	20 – السرعة القصوي	600 جرام	مكسرات
10-20 ثانية	1-20	700 جرام	سمك
10-20 ثانية	1-20	700 جرام	جبن

- يجب إبعاد السلك الكهربائي عن أي مصدر للحرارة، زيوت ساخنة و الحواف الحادة.
- برجاء الحذر عند حمل الشفرات لأنها حاده جدا، ممكن ان تقوم بالإمساك بها بواسطة الجزء البلاستيكي العلوي.
- لتقليل خطر الإصابة لا تضع أي من الشفرات أو الملحقات الأخرى أبدا علي قاعدة الموتور بدون وضع الشفشق في مكانه بشكل صحيح.
- تأكد أن الغطاء مغلق بشكل صحيح قبل تشغيل الجهاز.
- لا تقم بدفع الطعام في الجهاز أبدا بواسطة اليد دائما إستخدم دافع الطعام.
- لا تحاول تحدي طريقة عمل غالق الغطاء.
- دائما ضع غطاء الشفشق عند التشغيل.
- عند خلط السوائل الساخنة قم بإزالة الغطاء الصغير لشفشق الخلاط.
- لا تقم بإستعمال الجهاز إذا كان فلتر العصاره عطلان أو مكسور.
- يجب التأكد أن الجهاز مفصول عن مصدر التيار الكهربائي و ان مفتاح التشغيل علي وضع الإيقاف قبل ادخال أو إزالة اي من الملحقات.

قبل الإستخدام لأول مرة

- قم بإزالة جميع مواد التغليف.
- قم بإزالة أي ملصقات من على الجهاز.
- تأكد من وضع الجهاز على سطح مستو ونظيف وجاف وغير قابل للإنزلاق.

معلومات هامه:

من فضلك إقرأ كافة التعليمات التاليه بعناية من أجل حمايتك فإن الجهاز له وسيلة امان مزدوجه لذا لا يمكن تشغيله بدون إغلاق الغطاء الرئيسي (20) في مكانه و غطاء الأمان (1) مغلق شفشق الخلاط (12) أيضا مغلق بإحكام في مكانهم.

ملاحظات:

- 1- لفك غطاء الامان (1) أو لفك شفشق الخلاط (21) يجب عليك أولا إزالة الغطاء الرئيسي (20).
- 2- لتشغيل الجهاز يجب غلق غطاء الأمان (1)، لفتح غطاء الأمان قم بدفع زر فتح غطاء الأمان (2).
- 3- لتشغيل شفشق الخلاط (21) يجب وضع الغطاء الرئيسي (20) و غلقه بإحكام في مكانه.
- 4- عند تشغيل شفشق الخلاط (21) يجب التأكد أن جميع الأجزاء المرفقة قد تم إزالتها أولا من شفشق العجن (13).
- 5- لا تحاول أن تستخدم كلا من شفشق الخلاط و شفشق العجن في نفس الوقت.
- 6- لا تحاول فك غطاء الأمان (1) أو الغطاء الرئيسي (20) بقوة.