

SONAI[®]

Citrus Juicer - Squeezer

MAR-755




1 L

Instruction Manual



www.sonaiworld.com



1	Motor housing	4	Cone
2	Measurable Jug	5	Lid
3	Strainer	6	Power cord

Save These Instructions

While using electrical appliances, in order to reduce the risk of fire, electric shock, or injury to persons, basic safety precautions should be followed, including the following:

- Read all instructions carefully, even if you are familiar with the appliance.
- To protect against the risk of electric shock, DO NOT IMMERSE the appliance, cord set or plug in water or other liquids.
- To clean, wipe the exterior with a damp cloth.
- Close supervision is necessary when any appliance is used near children. Never leave an appliance unattended when in use.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

- Switch off and remove the plug from the power outlet when not in use before assembling or disassembling parts, cleaning or carrying out any maintenance of the appliance. Never pull the cord while unplugging out from power outlet.
- Do not operate the appliance if it is damaged in any manner. Return the complete appliance to your nearest authorized service facility for examination, electrical repair, mechanical repair or adjustments to avoid any hazard.
- The use of attachments or accessories not recommended or sold by Sonai may result in fire, electric shock or personal injury.
- Do not let the cord hang over the edge of a table, counter, or touch hot surfaces.
- Do not operate or place any part of this appliance on or near any hot surfaces (such as gas or electric burner or in a heated oven).
- Do not abuse the cord. Never carry the appliance by the cord or yank it to disconnect it from the outlet; instead, grasp the plug and pull to disconnect.
- When using an extension cord with your appliance, make sure the extension cord is correctly wired, and rated for its use.
- This product is intended for household use only.
- Do not attempt to repair the appliance yourself; instead, take it to your Authorized Service Centre for repair.
- Always leave sufficient space around the appliance for ventilation.
- Do not use the unit if you have wet hands or bare feet.
- Switch off the appliance before changing accessories or approaching parts which move in use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children must be supervised to ensure that they do not play with the appliance.

Before First Use

- Remove all the packaging material.
- Wipe the motor housing with a damp cloth & dry thoroughly.
- The parts of the juicer can be washed in warm soapy water. Rinse after cleaning & dry thoroughly with a soft dry cloth.

Cautions

- Do not wash any parts of the citrus juicer in a dishwasher.
- Do not use abrasives or chemical cleaners on any part of this juicer.
- Do not immerse the juicer, cord or plug in water or any other liquid.

How to use your citrus juicer

Use your Sonai citrus juicer to squeeze the juice from citrus fruits; oranges, limes and grapefruits.

- Place the juicer on a clean, flat work surface.
- Place the strainer on the jug and press the cone into the strainer until the cone engages.
- Connect the appliance to a suitable electrical outlet.
- Cut the fruit in half.
- Press a halved citrus fruit onto the cone, When the fruit is pressed down, the motor will start. The strainer will rotate, the cone will squeeze out the juice and the juice will flow into the jug.

Note: By pressing then releasing pressure, the cone may change the direction, it rotates to ensure that the maximum amount of juice is squeezed out of the fruit.

Cautions

- Do not press too hard on the cone or run for more than 1 minute.
- When juicing large quantities, empty the strainer regularly to prevent the build up of pulp and seeds

Cleaning

- Before cleaning, always unplug the citrus juicer
- Disassemble the appliance parts and wash in warm soapy water. Rinse after cleaning & dry thoroughly with a soft dry cloth.
- Wipe the motor housing with a damp cloth & dry thoroughly.
- Do not use abrasives or chemical cleaners on any part of this appliance.

Electrical Safety



Always check that the power supply corresponds to the voltage on the rating plate.

To avoid the risk of electric shock, do not immerse the cord, plug or motor unit in water or other liquid.

Protecting The Environment



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.

السلامة الكهربائية

التأكد من توافق محول الكهرباء مع الجهد الكهربائي للجهاز في لوحة البيان.
تجنب غمر السلك أو القابس في أى سوائل لتجنب خطر الصدمة الكهربائية.



حماية البيئة

تشير هذه العلامة إلى ضرورة عدم التخلص من المنتج بعد تلفه بالطرق العادية للتخلص من النفايات المنزلية في دول الإتحاد الأوروبي، لمنع حدوث أي أضرار محتملة تؤثر سلباً على البيئة أو صحة الإنسان نتيجة لإتباع طرق التخلص من المخلفات بصورة غير منضبطة أو إعادة تدويرها بشكل يسمح بإعادة استخدامها بصورة مستمرة. لكي يتسنى لك إعادة المنتج بعد استخدامه، يرجى إتباع أنظمة الإعادة والتجميع أو الإتصال بتاجر التجزئة الذي اشتريته منه المنتج حيث يمكنه تدويره بطريقة آمنة على البيئة.



تحذير

- لا تغسل أى جزء من عصارة الحمضيات فى غساله الأطباق.
- لا تستخدم المنظفات الكاشطه أو الكيماويه فى أى جزء من هذه العصارة.
- لاتغمر عصارة الحمضيات أو السلك أو القابس فى الماء أو أى سائل آخر.

كيفية إستخدام عصارة الحمضيات من سوناي

إستخدم عصارة سوناي للحمضيات للحصول على العصير من الفواكه الحمضية؛ مثل البرتقال والليمون والجريب فروت.

- ضع العصارة على سطح مستوى مناسب
 - ضع المصفاة على الإبريق واضغط علي المخروط في المصفاة إلى أن يتم تعشيق المخروط.
 - قم بتوصيل الجهاز بمصدر طاقة مناسب.
 - قم بقطع الفاكهة إلى جزأين.
 - اضغط الفاكهة الحمضية المقطوعة إلى نصفين على المخروط.
- عندما يتم الضغط على الفاكهة، يبدأ الموتور في العمل. تدور المصفاة، ويعصر المخروط الفاكهة، ويتدفق العصير في الإبريق.

ملاحظة: من خلال الضغط ثم التحرير، يمكن أن يغير المخروط اتجاه دورانه لضمان الحصول على أقصى قدر ممكن من الفاكهة.

تحذير

- لا تضغط بشدة على المخروط أو تجعله يعمل لمدة تتجاوز ١ دقيقة متصلة.
- عند عصر كميات كبيرة، قم بإفراغ المصفاة بشكل متكرر لمنع تراكم اللب والبذور

التنظيف

- قبل التنظيف، قم دائماً بفصل العصارة من مصدر التيار الكهربائي.
- قم بتفكيك أجزاء العصارة وغسلها بالماء الدافئ المحتوى على صابون. قم بالشطف بعد التنظيف، و قم بالتجفيف جيداً باستخدام قطعة قماش ناعمة جافه.
- امسح جسم الموتور بقطعة قماش مبللة و قم بتجفيفه جيداً.